STEP 1

Mount vertical and horizontal tracks as normal.

STEP 2

Mount quick closer on top panel as per diagrams below.

NOTE: 1: Illustration is based on FTG/PMT panel.

- 2: Right hand mounting (single endstile) shown only.
- 3: Use 2 quick closers per side with long axle wheel (P/No. 4484) for double endstile mounting.
- 4. Use self-drilling hex head screws for closer mounting.
- 5. Ensure top panel is in vertical position.
- 6. 2 sets of positions are allowed for wheel axle mounting. Use mounting (a) if headroom condition allows.

NOTE: 1: Use wheel mounting (b) if minimum headroom requirement is necessary.

- 2: If top panel with reo, mount it below quick closer as close as possible.
- 3: For double endstile door, mount inside quick closer 2-3mm higher than outside one to reduce wheel axle tilting at opening position.



